



# Voicemail Messaging With Fax Feature

## Accessing Your Mailbox

Thank you for choosing NTELOS voicemail messaging.

From your home or office phone, dial your own number or the pilot number you've been given.

Enter your security code.

If you hear your greeting first, press **#** and then enter your security code.

If dialing from a phone away from your office or home, you can either dial your number or the pilot number. When prompted for your mailbox number, enter your ten-digit telephone number associated with your voicemail service. Then enter your security code.

You may return to the main menu at any time while in your mailbox by pressing

**\* 1**.

To exit, simply hang up or press **\* 9**.

## Playing Messages

To play your messages, enter your mailbox and press **1**. Your messages will begin to play. Your options are to press:

- 1** to keep a message new
- 2** to save a message
- 3** to reply to a message
- 5** to delete a message
- 7** to redirect a message
- 8** to play the previous message
- \* 4** to recover deleted messages before you hang up

### FAX OPTIONS

When reviewing your messages you will hear that a fax message has been received. Your option are to press:

- 9 2** to print to your primary fax number
- 7 9** to print to another fax number enter **0 0**, then the 10-digit fax number, then **#**
- 9 3** if you are calling from a fax machine then press **\* 1** followed by **9 9** then press START on the fax machine

### PLAYBACK OPTIONS

At any time during a message you may press:

- #** to pause/continue playing a message
- 4** to rewind the message 6 seconds
- 4** to rewind the message to the beginning
- 6** to fast forward message 6 seconds
- 6** to fast forward to the end

## Personal Options

Log onto your mailbox. Press **8** for the Personal Options menu. Your options are to press:

- 2 3** to change your security code
- 8 3** to change playback mode
- 7 1** to play your fax number
- 7 3** to modify your fax number

## Global Commands

Following are some additional commands to help make using voice mail easy and efficient. Press:

- \* 1** to go to main menu
- \*** to backup or cancel
- \* \*** for additional help
- \* 9** to exit voice mail

## Multiple Greetings

Log into your mailbox. Press **2** for the greetings menu. Your options are to press:

- 2 1** to play your greeting
- 2 3** to record a greeting
- 2 5** to delete a greeting
- 3 1** to play your name
- 3 3** to record or change your name
- 3 5** to erase your name

## Record and Send a Message

Enter your mailbox. Press **3** to record a message. After recording your message, your options are to press:

- 3** to record/continue recording
- 5** to delete the recorded reply
- 7** for special delivery options, then press:
  - 1** to mark urgent
  - 2** to mark confidential
  - 3** to mark for notification of non-delivery
  - 4** to mark for future delivery
  - 5** to delete delivery tags
- 9** to address message
- #** to send message

## Broadcast Lists

Build a distribution list if you regularly send messages to more than one or two mailboxes. Press **6** from the main menu and follow the prompts.

For additional help, call 1-877-4-NTELOS.

A Customer Care representative will be glad to assist you.